



Product Installation Guide - ESL-WFR-Rss-yyW-32750-WH


⚠ WARNING

- 1. To avoid electric shock, disconnect power at source prior to installation.
- 2. The installation should be performed by qualified electricians or lighting technicians.
- 3. Before conducting any installation, maintenance, or removal, disable all power.
- 4. Do not touch the fixture while it is in service.
- 5. If there is any problem with the fixture, turn off power and DO NOT attempt repair unless you are a qualified technician or the customer service member.

Package Contents







J-Box Driver




Wire Connectors




Wafer Installation

HOLE SIZE


3 inch: 3 5/64" (78mm) 4 inch: 4 21/64" (110mm) 6 inch: 6 19/64" (160mm)




Create a cutout of the appropriate diameter using the template or the table above.




Open the J-Box cover and 2 remove the knockout(s) on the side panel. Insert the supply cable using appropriate cable clamps (not included) if necessary. Connect the supply wires to the Wafer wires using the 3 connectors.



Select your desired lamp color with the CCT Switch.



Insert J-Box through the mounting hole and secure it. Connect the Wafer's power cable to the J-Box.



Push the spring-loaded clips upwards 5 Push the spring-rouged supmounting hole. Release the clips and the fixture will be pulled flush into the ceiling.



Turn on the power and confirm $oldsymbol{\mathsf{O}}$ the fixture functions properly.

Copyright © 2022 ESL Vision, LLC. All rights reserved. Rev: 10/19/22

www.eslvision.com

888.493.5559